




Step by step instructions:

Cut out all pattern pieces, make sure to mirror all pieces except waistline and cuff.

Front:

<p>1) Arrange all your pattern pieces 1-2-3-4-5. (opt. M-O-N-S-T-E-R) Make sure you place the gussets right way up. I have added a grainline with arrow that shows up on all the pattern pieces.</p> <p>The notches on each piece should match each other.</p> <p>Capri: For Capri model follow the jeans instructions but leave out part 5 on the Front and on the Back, you use only part 1 and 2 (make sure you cut part 2 at Capri length)</p> <p>If you have chosen to sew without front pocket skip to step 5.</p>	
<p>2) Sew the pocket bag to part 1 (MO) right sides together.</p>	
<p>3) Fold the pieces wrong sides together. Press and topstitch along the top edge.</p>	

4)
Sew the pocket piece to the pocket bag.

Baste along the outer edge to keep the layers in place.



5)
Sew together all the front pieces 1-2-3-4-5. (M-O-N-S-T-E-R)

Press and topstitch.

*Make sure to fold the seam allowance the same way on both legs.

*Some machines have a smaller work area, if so you might prefer to divide this part, sewing part 1 to 2, press and topstitch, before 2 to 3 and continue.



6)
Attach the gusset to the front piece right sides together. Make sure to pin it thoroughly. Repeat for both legs.

*Make sure you turn the gusset the right way up. The picture shows how the gusset fit into the curve of the front and back piece. It seems too big because of the seam allowance.

It's very important to press the seams down to prevent "wavy" seams.



7)

Press the seam allowance towards the gusset and topstitch.



8)

Place both front pieces right sides together, then sew the crotch seam.

*This can be a bit challenging on your serger, you can also sew a stretch seam on your regular sewing machine.

*Use a glue pen to make sure the gusset seam doesn't move when sewing.

**You can baste in place with your regular machine to ensure this.



9)

Fold the mock fly, make sure to match the notches on top that show the centre of the waist, pin down.



10)

Topstitch, start at the bottom, and sew straight up. Then start at the lowest part of the mock fly and topstitch in a curve to the top.

Pull the loose threads at the bottom of the mock fly through to the backside and fasten.



Back:

11)

Get your pattern pieces 2-3.

The notches on each piece should match each other.

Sew together part 2 to 3. Press and topstitch.



12)

Pin the gusset to the back piece, right sides together. Sew together. Repeat on both legs.

*Make sure you turn the gusset the right way up. (see step 6 for picture) The picture shows how the gusset fit into the curve of the front and back piece. It seems too big because of the seam allowance.

Press the seam allowance towards the gusset and topstitch.

It's very important to press the seams down to prevent "wavy" seams.



13)

Place both back pieces right sides together, then sew the crotch seam. Press and topstitch.

*Use a glue pen to make sure the gusset seam doesn't move when sewing.

**You can also baste in place with your regular machine to ensure this.



14)

Locate the middle of part 1 by folding the piece in half and putting in a pin at the fold. Place the pin against the crotch seam (part 2), right sides together. Pin down, sew together, press the seam allowance upward and topstitch



Backpocket:

15)

Iron the fusible interfacing to the back of the pocket pieces.

*I recommend H180 interfacing.

Place the interfacing with the stretch horizontally.



16)

Press down the pocket fold along the line and topstitch.

17)

Fold down the top corners and fasten with a glue pen.



18)

Fold in the sides with 0,6 cm, use glue pen to fasten.



19)

Position the pockets according to the pocket placement shown on the pattern piece. Pin down. I recommend also using a glue pen generously.



20)

Sew the pocket to the back, strengthen the corners with a triangle. You may use a ditch or guide presser foot on your regular machine.

*Lift the presser foot when sewing to avoid wrinkles. Leave the needle down, lift the presser foot, loosen the fabric and continue sewing.



21)

Place back piece and front piece right sides together and sew the side seam. Press the seam allowance backwards and topstitch.

Repeat on both legs.



22)

Sew the inseam.

*Use a glue pen to make sure the gusset seam doesn't move when sewing.

**You can baste in place with your regular machine to ensure this.



Waistband and cuff:

<p>Waistband *I use the main fabric for both waistband and cuff, but you may also use rib fabric (Use rib chart for measurements)</p> <p>23) Fold waistband right sides together and sew the short ends together. Fold over right side out.</p> <p>24) Fasten the elastic (4 cm wide) creating a circle, overlapping by 1 cm, sew together. Fold the elastic into the waistband.</p> <p>*You can baste the waistband opening shut with the elastic inside to simplify the next step.</p>	
<p>25) Pin the waistband, with the elastic inside the fold, to the waist opening, right sides together. Sew together.</p> <p>26) Topstitch the waistband on a regular sewing machine, recommended stitch length 3,5 mm, around the waistline.</p> <p>Capri: Double fold the hem and stitch a single seam around the opening. You're finished your capris!!</p>	

Cuff:

27)

Fold the cuff, right sides together and sew the side seam.

*Make sure the grainline is the right way

28)

Gather the leg opening the leg opening. Pin the cuff to the leg opening right sides together and sew.



You have completed your MiNiMonster jeans!!!!

I hope you enjoyed the pattern and wish to share your creation with me. Facebook: Minimonster or instagram: @minimonstermamma

#minimonsterjeans #minimonsterdesign

Copyright MiNiMonster design

You may not copy, share, sell, distribute, or publish any part of this pattern or instructions.

It's only permitted to use pattern for small scale